






DRESSER

INSTRUCTION MANUAL / ИНСТРУКЦИЯ ЗА УПОТРЕБА




Ax4

Bx4





Cx8




Dx44

Ex4

Fx4



Gx4



Hx44




Ix8




Jx44




Kx36



Lx44



Mx8



Nx4

1

Nx4

1



3

3

3

3

3

4

Kx16

E4

3

3


3

3

4

2

Jx6






Lx6



4



Kx16



F4













*Didis LTD, Bulgaria
Shumen 9700, Trakia-iztok street №6
Tel. : +359 54 850 830
E-mail : home.market@didis-ltd.com
E-mail : export@didis-ltd.com*

*Дидис ООД, България
Шумен 9700, ул. Тракия-изток №6
Тел. : 054/850 830
E-mail : home.market@didis-ltd.com
E-mail : export@didis-ltd.com*